

Weightless Calibration for PX-Series Scales

1. Turn the scale ON and once the display shows the ROM version number, press the **TARE** key.



(The version should be "1.30b" or greater.)

2. The display will then show:



3. Press **G/N/T**, **G/N/T**, **G/N/T**, **G/N/T**, and then **TARE**.

4. The display will show:



and then




5. Press the **MODE** key until the display will look like this:



6. Press the **TARE** key.

7. The display will then look like this for a 60 pound scale:



8. When a scale is tested for accuracy, an Inspector will write down the reference weight he placed on the scale and what the scale displayed when he placed the reference weight on the scale. The reference weight he used is the **CapSet** point and the weight that the scale displayed at that set point is the **Error Weight**. The **CapSet** point is usually some percentage of capacity (see table) which you can select by using the **UNIT** key.

	PX-6	PX-12	PX-15	PX-30	PX-60
100%	6 lb (3 kg)	12 lb (6 kg)	15 lb (6 kg)	30 lb (12 kg)	60 lb (30 kg)
50%	3 lb (1.2 kg)	6 lb (3 kg)	7.5 lb (3 kg)	15 lb (6 kg)	30 lb (12 kg)
20%	1.2 lb (0.6 kg)	2.4 lb (1.2 kg)	3 lb (1.2 kg)	6 lb (2.4 kg)	12 lb (6 kg)
10%	0.6 lb (0.3 kg)	1.2 lb (0.6 kg)	1.5 lb (0.6 kg)	3 lb (1.2 kg)	6 lb (3 kg)

For example, if the Inspector used 6 lb to test the scale and when he placed the 6 lb on the scale it displayed 6.12 then **CapSet = 6 Pounds** and the **Error Weight = 6.1200**.

Once you have selected the **CapSet** point, press **TARE** and the display will show the **Error Weight** below:



9. This is the **Error Weight** and it can be from 0.0000 to 99.9999 and defaults to be the same as the **Set Point**.

Use the **G/N/T**, **UNIT**, **MODE**, and **ZERO** keys to set the **Error Weight** value; press **ZERO** to clear the Error Weight value:

- The **ZERO** key will always clear the entry and make the value = 0.000.
- The **▲** (or **UNIT**) key and the **▼** (or **MODE**) key will increase or decrease the Least Significant digit. This is the rightmost digit and it is the **ONLY** digit that can be changed by these keys.
- The **◀** (or **G/N/T**) key will multiply the value by 10.

For example, if the **Error Weight** value = 6.1200 then you need to press **▲▲▲▲▲▲▲▲◀◀◀◀◀◀◀◀**.

10. Once you have entered the **Error Weight** value, press **TARE** and press **ZERO** the key.

If further problems persist, please contact the Atron Systems Service Department at 973-227-8882.